

Easy, stable method of mounting an IP290 to the wall.

Purchase steel cover plate with 7/8" hole.

Measure down 1" from top and 1" from bottom.

Either drill a hole or use small self tapping screws.

Plain steel is OK.

Plug in the Ethernet/POE cable and mount the phone.

This should take about 10 minutes.

